


Thank you for buying Skunkx footwear. This foot warmer and massager provides daily comfort and relaxation by ensuring your feet are warm and relaxed. The warmth and massage functions increase blood flow circulation, providing hours of comfortable use.


## General description



### Keys and functions

1. Charger connector - to recharge your Skunkx.
2. Heat button - toggle between heat on and off.
3. Heat & battery low indicator - blinking green: heat on, light off: heat off, red: battery low recharge your Skunkx.
4. Massage button - toggle between massage on and off.

## Charging your Skunkx



Recharge the batteries of your Skunkx when the battery low indication light turns red. Fully charged batteries typically last for about 10 hours.

**Note:** charging normally takes 4-5 hours, but may take longer when the Skunkx are switched on while charging.

Plug the charger into a wall socket. The lights on the charger light up green. Now connect the charger to both shoes. The lights on the charger stay red as long as the Skunkx are not fully charged. When both lights on the charger turn green your Skunkx are fully charged and ready for use.

## Using your Skunkx

### Warming your feet

- Press the heat button to turn on the heater. The heat indication light will blink green. You should feel the Skunkx gradually warm up.
- Press the heat button again to turn off the heater. The heat indication light will be off.

**Note:** warming up takes roughly up to 3-4 minutes.

**Note:** the temperature cycles between 6 minutes heat on and 2 minutes heat off, this variation makes you feel the warmth better.

**Note:** for extra warming press the heat button once to activate the heater, then press again and hold for 3 seconds until the heat indicator is constant green. Your feet will stay warm at a constant 39°C. Press the heat button again to turn off the constant heat. The heat indication light will be off.

### Massaging your feet

- Press the massage button to turn on the massage. You immediately feel the vibration.
- Press the massage button again to turn off the massage.

**Note:** the massage automatically switches off after 30 minutes to prevent overstimulation of the feet.

**Note:** you can use your Skunkx in your house even when walking. However we do not recommend wearing the Skunkx outside in wet or rainy conditions.

**Note:** use your Skunkx also while you are on a plane. Many people get cold feet during long flights or want to stimulate blood circulation. It has been scientifically proven that Skunkx improve the blood flow in the feet.

## Environment



This product contains batteries that contain substances that may pollute the environment. Do not throw away your Skunkx with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

## Warranty

Skunkx have a warranty on electronics for a period of 12 months after the date of purchase. We guarantee during that period a free of charge repair or replacement of the product. This warranty extends only to the original purchaser. If the product proves defective during the warranty period contact Skunkx customer service accessible via [www.skunkx.com](http://www.skunkx.com). This warranty does not apply if the product has been altered, has not been operated, repaired, or maintained in accordance with instructions in the manual, has been subjected to abnormal physical or electrical stress, misuse, negligence, or accident, or when the product is not accompanied of this guarantee proof and proof of purchase. The shoes itself do not fall under this warranty. Every further liability, particularly indirect damage is excluded. This Warranty is valid and may be processed only in the country of purchase.

## Important

Please read this section carefully before you use your Skunkx and save this manual for future reference.

### General

- Skunkx are intended as an aid. It is NOT intended for medical use. In case of doubt, please consult your doctor to check if usage is allowed.
- Skunkx are primarily intended for indoor use.
- Its recommended to use the massage for a maximum of 15 minutes per hour. After 30 minutes the massage stops automatically to avoid overstimulation.

### Danger

- Never immerse any part of the Skunkx in water or any other liquid.

## Important

### Warning

- Never use or wear the Skunkx in moist places or close to water.
- Check if the voltage indicated on the charger corresponds to the local mains voltage before you connect the appliance.
- Only use the charger supplied to connect the Skunkx to the mains.
- The charger contains a transformer. Do not cut off the charger to replace it with other plugs, as this causes a hazardous situation.
- When the rubber of the sole shows wear and tear, so that it can't cover the electronics inside anymore, stop using the product immediately and contact your retailer when the product is within the warranty period.
- Never open your Skunkx or disassemble the inside accessories as it can cause shock or self-ignition of the battery and renders your warranty invalid, please contact your retailer.
- Do not put nails or other sharp items in the Skunkx sole or any other part, do not throw, fold or violently jump with your Skunkx in order to prevent accidents.

### Caution

- Use and store the appliance at a temperature between -10°C and 40°C.
- Do not expose Skunkx to extreme cold or heat or to direct sunlight. Do not put the Skunkx close to a heating source.
- Because Skunkx contain electronics, it is NOT recommended to immerse the Skunkx in water when cleaning, nor should you clean near a large volume of water. Do not wash or dry in a machine or put in a microwave. If the soles are dirty, use a slightly damp cloth to clean. DO NOT scrub, rinse or wipe near the interface as this may damage the electronics, or worse, result in harm for you.
- When not using Skunkx for a long period, store in a dry and cool place, and fully charge every 3 months.

## Customer Care

[www.skunkx.com](http://www.skunkx.com)


Please visit our service & support section on our website where you can find information such as:

- Cleaning and Maintenance
- Frequently Asked Questions



**Bedankt voor het kopen van Skunkx footwear.** Skunkx footwear verwarmt en masseert uw voeten en stimuleert de bloedcirculatie, zodat u nooit meer koude voeten heeft. Skunkx zorgen voor urenlange warme en ontspannen voeten.


## Algemeen



### Knoppen en functies

1. Oplader aansluiting - aansluiting voor het opladen van Skunkx.
2. Warmteknop - schakel de verwarming aan en uit.
3. Warmte & batterij indicator - knipperend groen: verwarming aan, geen licht: verwarming uit, rood: batterij leeg; Skunkx opladen.
4. Massage knop - schakel de massage aan en uit.

## Skunkx opladen



Laad de batterijen van uw Skunkx op wanneer de batterij indicator rood is. Bij volledig opgeladen batterijen is dit na ongeveer 10 uur gebruik.

**Notitie:** het opladen duurt normaal gesproken 4-5 uur. Het duurt langer wanneer de Skunkx zijn ingeschakeld tijdens het opladen.

Steek de oplader in het stopcontact. De lichtjes op de oplader worden nu groen. Steek de oplader vervolgens in beide Skunkx. Zolang de Skunkx nog niet volledig zijn opgeladen zijn de lichtjes op de oplader rood. Als beide lichtjes op de oplader groen worden zijn de Skunkx opgeladen en klaar voor gebruik.

## Gebruik

### Verwarming



- Druk op de warmteknop om de verwarming aan te zetten. De warmte indicator knippert groen. Uw Skunkx worden geleidelijk warmer.

- Nogmaals drukken op de warmteknop schakelt de verwarming uit. De warmte indicator is uit.

**Notitie:** het opwarmen duurt ongeveer 3-4 minuten.

**Notitie:** de verwarming is steeds 6 minuten ingeschakeld en 2 minuten uitgeschakeld, waardoor u de warmte beter voelt.

**Notitie:** om extra te verwarmen drukt u eenmaal op de warmteknop om de verwarming in te schakelen, daarna drukt u nogmaals en houdt u de warmte knop gedurende 3 seconden ingedrukt totdat de warmte indicator constant groen wordt. Uw voeten worden nu continu op 39°C verwarmt. Door nogmaals op de warmteknop te drukken schakelt u de constante warmte uit. De warmte indicator is uit.

### Massage



- Druk op de massage knop om de massage in te schakelen. U voelt de massage meteen.

- Druk nogmaals op de massage knop om de massage uit te schakelen.

**Notitie:** de massage schakelt na 30 minuten automatisch uit om overstimulatie te voorkomen.

**Notitie:** u kunt Skunkx gebruiken in huis, zelfs terwijl u loopt. Het wordt afgeraden om Skunkx te dragen in natte omgevingen of in de regen.

**Notitie:** draag uw Skunkx ook in het vliegtuig. Veel mensen hebben koude voeten tijdens een lange vlucht of willen de bloedcirculatie in voeten en benen stimuleren wanneer ze lang stilzitten. Het is wetenschappelijk bewezen dat Skunkx de bloedcirculatie in de voeten verbeteren.

## Milieu



Dit product bevat batterijen die stoffen bevatten die het milieu kunnen vervuilen. Gooi Skunkx daarom niet weg met het normale huisvuil. U kunt Skunkx inleveren bij een recycle verzamelpunt. Dit is minder belastend voor het milieu.

## Garantie

Skunkx hebben een garantie van 12 maanden na aankoopdatum. Wij garanderen gedurende die periode de kostenloze herstelling of vervanging van het product. Deze garantie is alleen voor de oorspronkelijke koper. Neem bij gebreken tijdens de garantieperiode contact op met de Skunkx customer service via [www.skunkx.com](http://www.skunkx.com). Deze garantie is niet van toepassing als het product is gewijzigd, niet bediend, gerepareerd of onderhouden in overeenstemming met de instructies in deze handleiding, of is blootgesteld aan abnormale fysieke of elektrische belasting, misbruik, nalatigheid of ongeluk of wanneer het product zonder dit garantie of aankoopbewijs wordt aangeboden. De schoenen zelf vallen niet onder deze garantie. Iedere verdere aansprakelijkheid is uitgesloten. Deze garantie is alleen geldig en mag alleen afgehandeld worden in het land van aankoop.

## Belangrijk

**Lees het volgende aandachtig door voordat u Skunkx gaat gebruiken en bewaar deze handleiding voor toekomstig gebruik.**

### Algemeen

- Skunkx zijn bedoeld als hulpmiddel. Skunkx zijn niet bedoeld voor medisch gebruik. In geval van twijfel, raadpleeg uw arts of gebruik is toegestaan.
- Skunkx zijn bedoeld voor gebruik binnenshuis.
- Het wordt aangeraden de massagefunctie maximaal 15 minuten per uur te gebruiken. De massagefunctie schakelt na 30 minuten automatisch uit om overstimulatie te voorkomen.

### Gevaarlijk

- Dompel Skunkx of delen van Skunkx nooit onder in water of een andere vloeistof.

## Belangrijk

### Waarschuwing

- Draag of gebruik Skunkx nooit in vochtige ruimtes of in de buurt van water.
- Controleer of het voltageniveau vermeld op de oplader overeenkomt met het lokale voltageniveau.
- Gebruik uitsluitend de bijgeleverde oplader.
- De oplader bevat een transformer. Snijd de oplader niet af en vervang de pluggen niet, hierdoor kunnen gevaarlijke situaties ontstaan.
- Wanneer de rubberen zool beschadigd raakt zodat de elektronische elementen aan de binnenkant niet meer bedekt zijn, stop dan onmiddellijk met het gebruik van Skunkx en neem contact op met de retailer indien dit binnen de garantie periode gebeurt.
- Maak de Skunkx niet open en verwijder de elektronische elementen niet, dit kan een schok of zelfontbranding van de batterijen veroorzaken waardoor de garantie vervalt. Neem contact op met uw retailer.
- Steek geen scherpe voorwerpen in de zolen van Skunkx of in andere delen van het product. Buig de Skunkx niet om. Verder wordt aangeraden om niet met Skunkx te gooien of er hard mee te springen.

### Onderhoud

- Gebruik en bewaar Skunkx tussen de -10°C en 40°C.
- Stel Skunkx niet bloot aan extreme kou, hitte of direct zonlicht. Plaats Skunkx niet op een hittebron.
- Dompel Skunkx niet onder in water om schoon te maken. Stop Skunkx ook niet in een wasmachine, droger of magnetron. Gebruik een vochtige doek om de zolen schoon te maken. Schrob of reinig niet in de buurt van het interface zodat de electronica niet beschadigd kan raken.
- Bewaar Skunkx op een droge en koele plaats en laad ze elke 3 maanden op wanneer u uw Skunkx een langere periode niet gebruikt.

## Customer Care

### [www.skunkx.com](http://www.skunkx.com)

Op onze website vindt u de service & support sectie met meer informatie over:

- Schoonmaken en onderhoud
- Meest gestelde vragen

© 2009 2M Engineering Ltd. All rights reserved. Skunkx® is a trademark of 2M Engineering Ltd. 2M Engineering Ltd. • De Run 4352 • 5503 LN Veldhoven • The Netherlands • [www.2mel.nl](http://www.2mel.nl)

